



ISO 9001:2008 ED ISO 14001:2004
Certificato Nr. 52691

VALPAINT S.p.A.
Via dell'Industria, 80 - 60020 POLVERIGI (AN) ITALY
Tel. +39 071 906383 (r.a.) - Fax +39 071 906384
E-mail: info@valpaint.it
C.F./P.IVA/R.I. di AN 01108220425
Capitale Sociale € 500.000,00 i.v.

www.valpaint.it • www.valpaintjungle.it

SC 00240

METEORE 8

Technical Sheet

NAME:

METEORE 8

TYPE:

textured coating

USE:

water based decoration paint for indoor use

TECHNICAL DATA

specific weight: 1.636 ± 30 gr/LT at 20°C

viscosity: ===

yield :

4 - 5 m²/LT (it may vary according to the roughness, porosity and surface absorption and to the method of application)

matt,

colours from the catalogue

packaging:

LT. 1 - LT. 4

on the surface:

1 hour at 20°C

overpainting :

6-8 hours at 20°C

below the painting:

48 hours at 20°C

dilution:

ready to use

DRYING TIME:

PREPARATION OF THE PRODUCT: system: Stainless steel trowel and spatula

APPLICATION:

coats: 1

APPLICATION CYCLE:

Spatula-Stroke Effect: Apply a coat of METEORE 8 gradually over a surface of approx. 1 - 2 m². Use the PV 43 Trowel and apply 10 - 15 cm long irregular strokes in all directions. While METEORE 8 is still wet, create semi-smooth relief and striped spatula strokes using the PV 43 Trowel, with 5 - 10 cm long strokes in all directions. After about 4 hours at 20°C smoothen with 220 / 260-grit sandpaper to remove any irregular clots and joints. Subsequently apply two different-coloured coats of LAME'. Between the first and second coat of LAME', wait at least 2 hours at 20°C. LAME' must also be applied with the PV 43 Trowel in all directions, leaving very little product on the surface.

Coverage: METEORE 8 roughly 1 litre for 4 - 5 m²; LAME' roughly 1 litre for 16 - 20 m² (one colour coat depending on the thickness of METEORE 8 applied).

Veined Effect (Vertical, Horizontal, Oblique): Apply a coat of METEORE 8 gradually over a surface of approx. 2 - 3 m². Use the PV 43 Stainless Steel Trowel and apply irregular strokes in the chosen direction. While METEORE 8 is still wet, create vertical streaks (or in another direction as desired) using the PV 84 Spatula and apply 20 - 35 cm long, soft strokes. After about 4 hours at 20°C smoothen with 220 / 260-grit sandpaper to remove clots and any irregular joints. Subsequently apply two different-coloured coats of LAME'. Between the first and second coat of LAME', wait at least 2 hours at 20°C. LAME' must also be applied with the PV 43 Trowel in the direction of the streaks, leaving very little product on the surface. Coverage: METEORE 8 roughly 1 litre for 4 - 5 m²; LAME' roughly 1 litre for 16 - 20 m² (one colour coat depending on the thickness of METEORE 8 applied).

Floral Effect: Apply a coat of METEORE 8 gradually over a surface of approx. 1 - 2 m². Use the PV 43 Trowel and apply 20 - 30 cm long irregular strokes in all directions. While METEORE 8 is still wet, apply continuous narrow and round strokes using the PV 84 Spatula. After about 4 hours at 20°C smoothen with 220 / 260-grit sandpaper to remove any irregular clots and joints. Subsequently apply two different-coloured coats of LAME'. Between the first and second coat of LAME', wait at least 2 hours at 20°C. LAME' must also be applied with the PV 43 Trowel in all directions, leaving very little product on the surface

Coverage: METEORE 8 roughly 1 litre for 4 - 5 m²; LAME' roughly 1 litre for 16 - 20 m² (one colour coat depending on the thickness of METEORE 8 applied).



ISO 9001:2008 ED ISO 14001:2004
Certificato Nr. 52691

VALPAINT S.p.A.
Via dell'Industria, 80 - 60020 POLVERIGI (AN) ITALY
Tel. +39 071 906383 (r.a.) - Fax +39 071 906384
E-mail: info@valpaint.it
C.F./P.IVA/R.I. di AN 01108220425
Capitale Sociale € 500.000,00 i.v.

www.valpaint.it • www.valpaintjungle.it

SC 00240

Smooth Effect: Apply one coat of METEORE 8 using the PV 43 Trowel with 15 - 20 cm long strokes in all directions. Wait for METEORE 8 to tighten up then smoothen it slightly using the clean Trowel with strokes in all directions. After 4 hours at roughly 20°C, smoothen the surface using 220 / 260-grit sandpaper to remove any irregular clots and joints then apply two different-coloured coats of LAME'. Between the first and second coat of LAME', wait at least 2 hours at 20°C. LAME' must also be applied with the PV 43 Trowel in all directions, leaving very little product on the surface.

Coverage: METEORE 8 roughly 1 litre for 12 - 13 m²; LAME' roughly 1 litre for 35 - 40 m² (one coat for each colour depending on the thickness of the underlying coat).

NB: For light shades (non-coloured METEORE 8) we recommend applying LAME' using the PV 91 Plastic Trowel

Application temperature: between +5°C and +30°C

Storage: make sure the tin is tightly closed, even after use, and stored at a temperature no lower than +10°C and no higher than +30°C.

Stability: approximately 2 years, if well sealed and never opened.

NOTES:

Mix carefully the product before use with an electric mixer (ie: drill with whisk) Application temperature must be between +5°C and +30°C. Wash the tools soon after use with water and soap.

Technical Sheet n° SC 00240 issued by the Control Responsible Department

Edition n° 1

September 2013

page 2 of 2